



Step-by-step
configuration of an
Airport Extreme







AirPort Utility - Base Station e946d1

Base Station e946d1

AirPort Extreme can share your Internet connection and USB devices on your network.

AirPort Extreme Name: testnet AE

Enter a password to protect the settings of this AirPort Extreme.

AirPort Extreme Password:


Verify Password:


Remember this password in my keychain


More Info...

Go Back

Continue








AirPort Utility - Network Setup

Base Station e946d1

Select what you want to do with AirPort Extreme.

- I want to create a new wireless network
- I want to replace an existing base station or wireless router with AirPort Extreme
- Extend the range of my AirPort Extreme, AirPort Express network

Go Back Continue



AirPort Utility - Network Setup

Base Station e946d1

Provide a name and security level for the wireless network.

Wireless Network Name: testnet

- WPA2 Personal**
Provides the maximum level of wireless security. Computers that support WPA2 will be able to join this network. You must enter a password between 8 and 63 characters or 64 hexadecimal characters.
- 128-bit WEP (more compatible)**
Provides security that is more compatible with older wireless computers and devices. To make it easier for non-Macintosh computers to join your network, enter a password of exactly 13 characters.
- No security**
Any wireless device can join your network without entering a password.

Wireless Password: [password field] [key icon]


Verify Password: [password field]

Remember this password in my keychain

More Info...

Go Back

Continue



AirPort Utility - Internet Setup


Base Station e946d1

AirPort Extreme is currently connected to the Internet using a DSL or cable modem, or over Ethernet with an IP address assigned automatically using DHCP. Confirm this or enter any optional information you received from your Internet service provider or network administrator.

I connect to the Internet with a DSL or cable modem using DHCP
 I do not use DHCP

IP Address: 192.168.1.156
Subnet Mask: 255.255.255.0
Router Address: 192.168.1.1
Domain Name: [text input field]
DHCP Client ID: [text input field]

Go Back Continue



AirPort Utility - Summary

Base Station e946d1

AirPort Extreme will use the settings below. Make sure they are correct.

AirPort Extreme Name **testnet AE**
Base Station Password ●●●●●●

Wireless Mode Create a wireless network
Wireless Network Name **testnet**
Wireless Security **WPA2 Personal**
Wireless Password ●●●●●●

Connect Using Ethernet
Configure IPv4 Using DHCP
IP Address (Provided Automatically)

If these settings are correct, click Update to finish setting up this AirPort Extreme. Click Go Back to change settings.

Go Back Update




This device and its network services will be temporarily unavailable. Are you sure you want to continue?

Do not show this warning again

Cancel

Continue




AirPort Utility - Summary

Base Station e946d1

Writing the AirPort Extreme configuration...

Go Back Update




AirPort Utility - Summary

The settings for this AirPort Extreme have been successfully updated. You can close this window or wait for this AirPort Extreme to restart.

⚙️ Waiting for the AirPort Extreme to restart...

Go Back

Update



AirPort Utility - testnet AE



testnet AE

Your AirPort Extreme is set up to connect to the Internet and share a USB printer. If you're using a cable modem to connect to the Internet, turn the modem off, remove the battery if it has one, wait a few seconds, put the battery back in, and then turn the modem back on.



Setup Complete

Click Quit if you are done making changes to any AirPort wireless device. If you want to set up another AirPort wireless device, select it from the list.

Go Back

Quit

AirPort: On
Turn AirPort Off

✓ShinerNet2	🔒	📶
RubyMonkey	🔒	📶
RubyMonkey-guest		📶
Sunset-X	🔒	📶
taipan	🔒	📶
testnet	🔒	📶


Join Other Network...
Create Network...
Open Network Preferences...

📶 🔊 🔌 (95%) 🇺🇸 3:40 PM pv C

AirPort: On
Turn AirPort Off

✓ testnet	🔒	📶
mypad	🔒	📶
RubyMonkey	🔒	📶
RubyMonkey-guest		📶
ShinerNet2	🔒	📶
Sunset-X	🔒	📶
taipan	🔒	📶

Join Other Network...
Create Network...
Open Network Preferences...



AirPort Utility - testnet AE


testnet AE

Your AirPort Extreme is set up to connect to the Internet and share a USB printer. If you're using a cable modem to connect to the Internet, turn the modem off, remove the battery if it has one, wait a few seconds, put the battery back in, and then turn the modem back on.

Setup Complete

Click Quit if you are done making changes to any AirPort wireless device. If you want to set up another AirPort wireless device, select it from the list.

Go Back Quit



AirPort Utility

- testnet AE
-
-
-
-

AirPort Utility found an AirPort Extreme 802.11g.

AirPort Extreme Name: testnet AE
IP Address: 10.0.1.1
Version: 5.7
AirPort ID: 00:03:93:E9:46:D1

If this isn't the AirPort wireless device you want to set up, you can select another from the list on the left. If you don't see it, make sure it is plugged in and in range of your computer.

Click Continue to change settings on this AirPort Extreme.

Manual Setup Go Back Continue

